

INSTRUCTION LEAFLET

Supersedes Leaflet No.

SAFETY NOTES:

- 1 This part should **ONLY** be fitted by suitably qualified persons having technical competence, applicable product knowledge and suitable tools and test equipment.
- 2 Servicing of electrical appliances must be undertaken with the appliance disconnected (unplugged) from the electrical supply.
- 3 Servicing must be preceded by Earth Continuity Earth Resistance & Insulation Resistance Checks.
- 4 Personal safety precautions must be taken to protect against accidents caused by sharp edges on metal and plastic parts.
- 5 After servicing, the appliance must be rechecked for Electrical Safety.

ALTERNATIVE DISHWASHER CONSOLE / DASHBOARD

Where the original part is no longer available, the enclosed Console / Dashboard has been supplied as a suitable alternative. The supplied part may be different in appearance to the original fitted to the appliance:

The possible differences are:

1. The model number printed on the front of the Console / Dashboard supplied may not be the same as shown on the original or on the appliance rating plate label. **
2. Where the original part had **text** and **symbols** to describe the Programmes and Options, the Console supplied may **only** have **symbols**.
3. In all other respects this part is the same as the original.

If necessary, refer to the original User Handbook for operating instructions. A Quick Guide to the symbols is provided below for the user.

Note to the Engineer / Repair Agent:

1. Please advise the user why this part is different in appearance to the original.
2. ** Please advise the user that when booking any future Service Calls or ordering Spare Parts that the Brand, Model Number and Serial Number details to quote **MUST** be those printed on the appliance rating plate label. This will ensure that the correct parts are supplied.
3. Please show the user where the rating plate label is situated.
4. **Leave this leaflet with the user so that they have access to the Quick Guide below.**

